




Stay connected in the classified world.

BluVault is a facility-wide solution to allow mobile phone communication inside secure spaces.



How BluVault Works

1. User's cubicle

Once you have paired your phone with an assigned BluVault cubicle, engage the system by pressing the "Connected" button on the front of the adapter. Place your phone in the wall-mounted locking cubicle outside the restricted area.

2. Internal phone system

Your internal phone system will now automatically route all calls from your BluVault-connected phone to a predetermined internal line, such as your desk phone. BluVault is transparent to callers, call recipients and mobile service providers.

3. User's desk phone

Your mobile phone essentially becomes a new "outside line" on your desk phone for placing or receiving mobile phone calls. Caller ID data from incoming calls is passed along to your phone's display.